STIRLING

25L AIR FRYER OVEN

WITH 10" PIZZA STONE

QUICK START GUIDE

Getting Started:

Please refer to the Instruction Manual for full instructions on how to operate the Air Fryer Oven.

WARNING: The temperature of the outer body can get very hot during and after use of the Air Fryer Oven. Allow the unit to cool down before cleaning or packing the unit away for storage.

NOTE: To help you get started using the Air Fryer Oven, we have included a recipe booklet for your enjoyment.

NOTE: The 8 prong rotisserie set is very sharp and is embedded in the foam packaging for your safety. Please make sure you carefully remove the 8 prong rotisserie set from the foam before you dispose of the packaging.

1. Before First Use

Wash the rotisserie set, rotisserie handle, air fryer basket, wire rack, crumb tray and bake tray in warm, soapy water, then dry thoroughly.

2. Find a Suitable Position

Place on a flat, dry, heat resistant surface and ensure you remove all contents including packaging that have been packed inside the Air Fryer Oven. Plug the cord into a power outlet and switch on.

3. Prepare the Ingredients

Prepare your food beforehand. Once ready, insert the suitable accessory into the Air Fryer Oven together with the food to be cooked. Refer to the instructions on page 10 of the instruction manual for which accessory is suitable for what type of cooking.

4. Using the AIR FRY Presets

Press the AIR FRY button to unlock the LED display panel. Use the FUNCTION dial to scroll through the presets until the desired preset icon flashes on the LED display panel. Then press the START/STOP button to commence cooking at the default time and temperature.

5. Using the OVEN Presets

Press the OVEN button to unlock the LED display panel. Use the FUNCTION dial to scroll through the presets until the desired preset icon flashes on the LED display panel. Then press the START/STOP button to commence cooking at the default time and temperature.

6. Once Finished

Once the timer has elapsed, the Air Fryer Oven will beep and return to standby mode. Switch off and unplug from the power outlet. Using oven mitts, remove the cooked food from the oven and place on a heat resistant surface.

AIR FRY Function:		
Preset	**Temp (°C)**	**Time**
Chips	200°C	22 mins
Wings	200°C	15 mins
Chicken	180°C	25 mins
Fish	180°C	15 mins
Steak	200°C	9 mins
Shrimp	180°C	8 mins
Dehydrate	80°C	9 hours

OVEN Function:		
Preset	**Temp (°C)**	**Time**
Bake	170°C	30 mins
Biscuits	170°C	30 mins
Pizza	190°C	16 mins
Bread	200°C	8 mins
Cake	170°C	27 mins
Grill	200°C	20 mins
Thaw	80°C	10 mins

WARNING: The accessories inside the oven will be very hot once cooking has finished. Always use oven mitts or other non-metal tongs or utensils to remove the accessories and the food from the Air Fryer Oven, never use your hands.

WARNING: Never immerse the Air Fryer Oven, cord or plug into water or any liquid.

NOTE: You may notice a slight odour being emitted from the Air Fryer Oven during the initial use. This is normal and will cease with continued use.

NOTE: Refer to page 16 of the instruction manual for how to adjust the temperature and timer.

Model	**IA4651**
Power	**1700W**
Warranty	**1 Year**
After Sales Support	**1300 777 137**

STIRLING

v1.1