

# STIRLING<sup>®</sup>

## 70L ELECTRIC OVEN



### Features:



Stylish & practical  
push pull knobs



An impressive  
70L usable capacity



Triple glazed  
removable door  
for safety



Buy with confidence.  
Supported by a 3 year  
in home warranty

# Quick Start Guide

## Installing the oven (refer to user manual)


**IMPORTANT:** The oven must be professionally installed by a licensed electrician. See the full instruction manual for installation instructions and a few preparatory steps before first use.

## Setting the Time


### Step 1

When the oven is first connected to the electrical supply correctly, the display will automatically show "12.30". An audible beep will then sound once and the "12" will flash. Before using the oven, please follow these instructions to ensure the correct time of the day is set.

### Step 2

To set the time once the "12" is flashing, press "+" or "-" button to adjust the hour setting. Once the hour time is set, press the  to confirm the hour setting. The minute part will now be flashing.

### Step 3

Press "+" or "-" button to adjust the minute setting. Once the minutes time is set, press the  to confirm the minutes setting and return the timer to standby mode. Your oven is now ready to use.

### Please Note

- That is 24 hour clock, i.e. 2 p.m. is shown as 14.00
- To adjust the time at any time, hold down the "+" and "-" buttons at the same time for at least 3 seconds until the hour display starts to flash.

Model Number	SO65B
Functions	5
Warranty	3 years

For more information please call 1300 11 43 57  
or visit [www.stirlingappliances.com.au](http://www.stirlingappliances.com.au)

Version 1.2




Fig. 1

- A. Function Selector
- B. LED Display & Timer Controls
- C. Temperature Control

### Functions



Oven Lamp



Defrost



Grill



Grill with top element & fan



Convection

