

STIRLING[®]

34L MICROWAVE OVEN

Multistage Cooking
10 Power Levels



Features:



10 Power Levels

Microwave cooking power adjustable from 10% to 100% in 10 power levels.




1000W Power

Microwave power output for cooking, defrosting and reheating food.



Multistage Cooking

Set consecutive cooking sequences for multistage cooking.



LED Display Screen

Electronic control panel with easy to read LED display screen.

Quick Start Guide

Read the full instruction manual thoroughly before use. It contains comprehensive usage instructions and important safety advice. This Quick Start Guide only contains a description of the most important control panel buttons.

Control Panel



DISPLAY - Cooking time, power, action indicators and clock time are displayed.

POWER LEVEL - Press to set a power level and to check the power level during cooking.

WEIGHT DEFROST - Press to defrost frozen meat, poultry and seafood by weight.

TIME - Press to set the cooking time.

JET DEFROST - Press to defrost food based on the time entered.

CLOCK - Press to set the microwave oven clock.

MEMORY - Press to set a multistage cooking program.

PRESET - Press to set a preset start time.

EXPRESS - Press to program the oven for 4 popular microwave timings at high power.

NUMBER PADS (0-9) - Press to set times or weights.

CANCEL - Press to clear the selected power level, or the previously set cook or defrost times.

START - Press to start a cooking or defrosting program. The cooking indicator light and the oven light will turn on and the cooling fan will operate.

Model Number	STR-G34M-W
Colour	White
Microwave Power Output	1000W
Capacity	34L
Warranty	3 Year
Version	QSG-V1.0

For more information please visit www.stirlingappliances.com.au or call 1300 886 649

