

STIRLING[®]

54CM FREESTANDING ELECTRIC COOKER



Features:



83L gross
capacity



4 solid element
cooking zones



5 oven
functions



Buy with confidence.
Supported by a 3 year
in home warranty

Quick Start Guide

Installing the oven (refer to user manual)

IMPORTANT: The oven must be professionally installed by a licensed electrician. See the full instruction manual for installation instructions and a few preparatory steps before first use.

Your electric cooking functions explained

Lamp

Which enables the user to observe the progress of cooking without opening the door. Oven lamp will light for all cooking functions.

Grill

Suitable for cakes when even rising and top colour is required

Grill with Fan

The upper heating element and the fan operate together. Suitable for Grilling food without turning over and using two shelves. Do not use lowest shelf position

Normal Fan-forced Cooking

The rear circular heating element and the fan operate together to assist in evenly cooking foods. This mode is ideal for general purpose cooking on 3 shelves at the same time.

Defrosting Mode

Only the fan operates. It is located on the back of the oven, causing makes the air to circulate at room temperature around the food .This is recommended for the defrosting of all types of food ,but in particular for delicate types of food which do not require subsequent cooking ,such as for example :ice cream cakes ,cream or custard desserts ,fruit cakes .By using the fan ,the defrosting time is approximately halved.

Model Number SUC54EEW

Functions 5

Warranty 3 years




Fig. 1

- A. Function Selector
- B. Temperature Selector
- C. Manual Minute Timer
- D. Cooking Zone Controls




Fig. 2

Solid Hotplates

- 1. Electric heating plate 1500W
- 2. Electric heating plate 1000W

For more information please call 1300 11 43 57
or visit www.stirlingappliances.com.au