

STIRLING[®]

Black Edition



Air Purifier

Model Number EPI208

INSTRUCTION MANUAL

AFTER SALES SUPPORT

  1300 886 649

 info@tempo.org

MODEL: EPI208 PRODUCT CODE: 63676 01/2019



E209

Welcome

Congratulations on choosing to buy a STIRLING® product.

All products brought to you by STIRLING® are manufactured to the highest standards of performance and safety and, as part of our philosophy of customer service and satisfaction, are backed by our comprehensive 2 Year Warranty. We hope you will enjoy using your purchase for many years to come.

Contents

- 02 Welcome**
- 04 Warranty Details**
- 05 General Safety Instructions**
- 08 Product Overview**
- 10 Getting Started**
- 12 Instructions**
- 15 FAQs & Troubleshooting Guide**
- 16 Other Useful Information**
- 19 Repair and Refurbished Goods or Parts Notice**



Air Purifier

Warranty Details

REGISTER YOUR PURCHASE AT www.aldi.com.au/en/about-aldi/product-registration/ TO KEEP UP-TO-DATE WITH IMPORTANT PRODUCT INFORMATION

The product is guaranteed to be free from defects in workmanship and parts for a period of 24 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and to compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



AFTER SALES SUPPORT

1300 886 649

info@tempo.org

MODEL: EPI208 PRODUCT CODE: 63676 01/2019

General Safety Instructions

READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

Read this manual thoroughly before first use, even if you are familiar with this type of product. The safety precautions enclosed herein reduce the risk of fire, electric shock and injury when correctly adhered to. Make sure you understand all instructions and warnings. Keep the manual in a safe place for future reference, along with the completed warranty certificate, your purchase receipt and the original packaging. If you sell or transfer ownership of this product, pass on these instructions to the new owner.

Always follow basic safety precautions and accident prevention measures when using an electrical appliance, including the following:

Electrical safety and cord handling

- **Electrical connection:** The unit comes with a plug ready for connection to your mains power outlet. Ensure your electrical outlet is properly installed and earthed and complies with your local electrical safety requirements.
- **Voltage:** Before turning on the air purifier, ensure the electrical voltage and circuit frequency correspond to those indicated on the appliance.
- **WARNING!** To reduce the risk of electrocution, never immerse the appliance in water or other liquid; never spill liquids into it. Do not place or store it where it can fall or be pulled into a tub or sink. If it accidentally has fallen into water, do not reach into the water. Immediately unplug it, let it dry and have it checked by an authorised service technician.
- **Protect from moisture:** Do not operate the appliance with wet hands. Do not use it in a bathroom or laundry, or where it can be splashed with water.
- **Power supply cord:** Do not kink or damage the cord. Do not pull the cord or place it near a heat source; keep it away from heated surfaces. Always unwind the cord completely to avoid overheating. Run the cord in such a way so that no one will trip over it.
- **Extension cord/adaptor:** Do not use this appliance with an extension cord or power adaptor.
- **WARNING!** To reduce the risk of fire or electric shock, do not use this appliance with any solid-state speed control device.
- **Damaged cord:** If the supply cord is damaged, do not use the appliance. A damaged power supply cord must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- **WARNING: Do not use if damaged!** In case of damage, switch off the product, unplug it and contact our after sales support centre. Do not pick up or operate a damaged appliance, or after it malfunctions or has been dropped or damaged in any manner.

General Safety Instructions (Cont.)

- **RCD:** The installation of a residual current device (safety switch) is recommended to provide additional safety protection when using electrical appliances. It is advisable that a safety switch with a rated residual operating current not exceeding 30mA be installed in the electrical circuit supplying the appliance. See your electrician for professional advice.
- **WARNING: Do not use if damaged!** In case of damage, do not use the appliance. Switch it off, unplug it and contact our after sales support centre. Do not pick up or operate a damaged appliance, or after it malfunctions or has been dropped or damaged in any manner.
- **Switching on/off:** Do not use the mains plug to start and stop the unit; always use the POWER button to start and stop the unit.
- **WARNING!** Turn off the unit first and then unplug it when it is not in use and before maintenance or cleaning. Grip by the plug, do not pull by the cord when disconnecting.

Usage conditions and restrictions

- **Intended use:** This appliance is intended for purifying indoor air in domestic environments. It is not suitable for commercial, industrial or trade use. Do not use it for any other purpose, and only use it as described in this manual.
- **Common sense:** These instructions are not intended to cover every possible condition and situation. As with any electrical appliance, common sense and caution are therefore always recommended when installing, operating and maintaining the unit.
- **No outdoor use:** Do not use the unit outdoors. It is for indoor use only.
- **Usage restriction:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- **Children:** Supervise children to ensure they do not play with the appliance. Close supervision is necessary when any appliance is used by or near children. Cleaning and user maintenance shall not be made by children without supervision.
- **Unattended:** Do not leave the appliance unattended when in use.
- **Openings:** Do not obstruct the air intake or outlet openings. Do not insert any objects, or your fingers into openings.
- **Attachments:** The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury.

General Safety Instructions (Cont.)

- **Handle with care:** Do not shake the appliance vigorously or drop it from an elevation. Doing so will damage the product or shorten its lifespan. Do not sit or stand on the appliance, which may lead to potential injury.
- **Location:** Always place the air purifier on a dry, stable, level and horizontal surface. Do not use the appliance near appliances that get hot during use, such as heaters, ovens or fireplaces.
- **Clearances:** Make sure there is at least a 15cm clearance from any walls and 1m from any heat sources such as stoves, radiators, or heaters.
- **Moving the appliance:** When moving the air purifier, always turn it off first and disconnect the power supply, and move it slowly. Keep the unit upward during transport and storage.
- **Liability:** We assume no responsibility for any eventual damages caused by improper installation, faulty use or failure to follow the instructions in this manual.

Cleaning and maintenance

- **Disconnect:** Make sure the appliance is disconnected from the power supply when it will not be used for a long time and before carrying out any cleaning or maintenance.
- **Service:** The air purifier has no user-serviceable parts contained inside. Do not attempt to disassemble, modify or conduct repairs on this unit. It has been built in accordance with relevant safety and performance standards. An electrical specialist must carry out all repairs. If the appliance requires service, please contact our after sales support centre.
- **Cleaning:** Clean the outside of the unit once a month using a dry or slightly damp cloth (not wet!), or use a soft brush attachment of a vacuum cleaner. Never use water, wax, polish, or any other chemical solution to clean the outside of the unit. Never use water or any household cleaners or detergents to clean the HEPA or carbon filters (only the prefilter made of sponge material is washable). Under normal usage conditions, replace the HEPA filter every 3 months and the carbon filter every 6 months.

Product Overview


Scope of delivery

A Air purifier

- 1 Control panel
- 2 Air quality indicator light
- 3 Front panel
- 4 Power cord and plug (at the back)
- 5 Base
- 6 Air outlet
- 7 Recessed handle (at the back)

B Documentation (not shown)

- Instruction manual
- Quick start guide
- Warranty certificate




NOTE: Due to continued product improvement, images and illustrations in this manual may vary slightly from the product purchased. All images in this manual are for reference purposes only. Parts are not necessarily pictured to scale.

Product Overview (Cont.)

Control panel

Fig. 1



- A TIMER button (and separate indicators: 1H, 2H, 4H, 8H)
- B CHILD LOCK button (and indicator)
- C POWER button (and indicator)
- D FILTER RESET button (and indicator)
- E SPEED/MODE button (and separate indicators: 1, 2, 3, Sleep, Turbo, Auto)

NOTE: When pressing a button, the appliance will acknowledge with a beep sound when a command has been received.

Getting Started

Introduction

The STIRLING® Air Purifier is designed to help you keep your home clean and free of air pollutants and allergens. Its effective 3-part filtration system filters out 99.5% of very small particles from common indoor air pollutants.

Bigger breathable particles, such as pet hair and dander, are trapped in a washable prefilter. An E12 HEPA filter removes at least 99.5% of very small airborne particles (0.3 microns) such as dust, pollen and smoke. And an activated carbon filter attracts and adsorbs harmful or undesirable fumes and odours from cleaning, cooking or new furniture.

Features

The STIRLING® Air Purifier is equipped with the following features:

- Control panel with touch controls for easy operation
- Air quality indicator light (green = good, blue = average, red = poor)
- 8 hour timer
- Child lock
- Sleep mode
- Filter replacement reminder
- Auto switch-off when disassembled


Before first use

- **Unpacking:** This product has been packaged to protect it against transportation damage. Unpack the appliance and keep the original packaging materials in a safe place. It will help prevent any damage if the product needs to be transported in the future, and you can use it to store the appliance when it is not in use. In the event that the packaging is to be disposed of, please recycle it where possible.
- **Safe packaging disposal:** Plastic wrapping can be a suffocation hazard for babies and young children, so ensure all packaging materials are kept out of their reach and disposed of safely.
- **Inspection:** Unwind the cord fully and inspect it for damage. Do not use the appliance if any part is damaged. In case of damage, contact our after sales support centre for advice.
- **Documentation:** Make sure you have read and understood all instructions and warnings in this manual. Refer the Product Overview section to identify all parts of the appliance and familiarise yourself with its operating principles. Pay particular attention to the safety instructions on the previous pages.
- **IMPORTANT!** Before first use you will have to unpack the filters and install them into the appliance. Instructions follow on the next page.



Getting Started (Cont.)

Assembly

Before using the appliance, you will have to remove all packaging materials from the filters, which are fitted inside the appliance in their original wrapping. They fit into the appliance in the order shown in Fig. 2.



1. Holding the front panel by the upper part, remove it from the appliance (Fig. 3).
2. Remove the packaged prefilter and E12 HEPA filter from the appliance – they are stuck together with hook-and-loop fasteners. Then remove the carbon filter, which is located behind them.
3. Remove all packaging materials from the filters.
4. Place the unpacked filters back into the appliance in the order shown in Fig. 1, making sure the sides with the tags are pointing towards you (Fig. 4).
5. To reattach the front panel (Fig. 5), mount the panel onto the bottom of the appliance first (1). Then gently push the panel against the body of the appliance (2).



Instructions

Using the air purifier

Connecting the appliance

- Plug the appliance into a properly earthed 220–240V~ 50Hz mains socket and switch on power to the outlet. All indicators will turn on with a beep sound for 2 seconds and then turn off.
- Press the POWER button to run the unit in Auto (default) mode. The appliance will start up and on the control panel, the power, Auto mode and fan speed indicator lights will turn on. At the front panel, the air quality indicator light will also illuminate.
- Press the POWER button in any normal mode of operation and the appliance will be shut down to standby mode.

NOTE: If you open the front cover when the unit is operating, the machine will shut down automatically and the power light flashes.

Air quality status

When the appliance is switched on, the air quality sensors inside the appliance assess the air quality and, after a short while, display the colour that corresponds to the current ambient air quality on the front panel.

Fig. 6



Green = good

Blue = average

Red = poor

Auto mode

When the appliance is operating in Auto mode (and the auto mode indicator is illuminated), the air purifier automatically controls the fan speed based on the air quality. You can change the fan speed or operating mode by pressing the SPEED/MODE button, repeatedly.

Instructions (Cont.)

Changing the fan speed/mode

- The **1st press** of the SPEED/MODE button turns off Auto mode and turns on manual mode. The fan speed is set to low speed (1) and the respective indicator turns on. Other features remain unchanged.
- The **2nd press** of the button changes the fan speed to medium (2) and the respective indicator turns on. Other features remain unchanged.
- The **3rd press** of the button changes the fan speed to high (3) and the respective indicator turns on. Other features remain unchanged.
- The **4th press** of the button switches the unit to Sleep mode: the respective indicator turns on and the fan speed changes to low. Other indicator lights turn off or are dimmed and the buzzer is turned off. Press any button to exit Sleep mode and return to Auto mode.
- The **5th press** of the button switches the unit to Turbo mode: the respective indicator turns on and the fan speed changes to high.
- The **6th press** of the button switches the unit back to Auto mode and the respective indicator turns on. Other features remain unchanged.
- Press the SPEED/MODE button again, repeatedly, and you will toggle through the fan speeds and modes, as follows: Auto → 1 → 2 → 3 → Sleep → Turbo → Auto ...

Timer setting

Make sure the appliance is switched on before setting the timer.

- The **1st press** of the Timer button activates the 1 hour timer and the respective indicator (1H) turns on. The machine will start timing and shut down automatically after 1 hour.
- The **2nd press** of the Timer button activates the 2 hour timer and the respective indicator (2H) turns on. The machine will start timing and shut down automatically after 2 hours.
- The **3rd press** of the Timer button activates the 4 hour timer and the respective indicator (4H) turns on. The machine will start timing and shut down automatically after 4 hours.
- The **4th press** of the Timer button activates the 8 hour timer and the respective indicator (8H) turns on. The machine will start timing and shut down automatically after 8 hours.

Instructions (Cont.)

Child lock

The air purifier is equipped with a child lock, which locks all buttons to prevent children from changing settings while the appliance is operating.

- To activate the child lock mode, make sure the appliance is in operation.
- Press and hold the CHILD LOCK button for 3 seconds and the respective indicator will turn on with a beep. All other buttons will now be locked.
- Press and hold the CHILD LOCK button again for 3 seconds to cancel the child lock mode and restore access to other buttons.

Filter reset button

The air purifier has a filter indicator built in that automatically counts the usage time and reminds you when the filters need to be replaced.

When you start the machine, the filter indicator begins counting the hours of usage. It will stop counting when the appliance is shut down or in standby mode and resume counting when you switch it on again.

When the filter indicator has counted a total of 2000 hours, the FILTER RESET indicator will start flashing to alert you to replace the filters.

- To replace the filters, follow the instructions on page 16.
- To clear the accumulated time after you have replaced the filters, press and hold the FILTER RESET button for 3 seconds. The machine will emit a beep sound and clear the accumulated time, and the indicator will turn off.

FAQs & Troubleshooting Guide

If you experience problems with your air purifier, or it appears not to be operating correctly, check the information below for solutions to common problems. If none of the solutions offered help you solve your problem, please contact our after sales support centre for advice.

Do not attempt to repair the appliance yourself!

Problem	Possible cause	Solution
The machine does not switch on.	Power is not properly supplied.	Make sure the appliance is properly connected to your power supply and your electrical outlet is working.
	The electrical outlet is faulty.	Check whether the appliance is working if connected to a different power outlet.
	The appliance is not switched on.	Ensure you have pressed the POWER button to switch on the appliance.
	The front cover is loose.	Ensure the front cover is properly fixed to the front of the unit.
The appliance makes a loud noise.	The air purifier is located on an inclined surface.	Place the unit on a level surface.
	The filter is clogged.	Check all three filters and clean or replace them as necessary.
	The air inlet is blocked.	Check and ensure that the air inlet and outlets are free of obstructions.
There is an unpleasant odour coming from the machine.	The filters need to be changed.	Replace the filters according to the instructions.
There is a burnt smell.	The unit is faulty.	Switch off and unplug the unit, then contact our after sales support centre.

Other Useful Information

Electric shock hazard!

Before cleaning and servicing, ensure the unit is switched off and disconnected from the power outlet to prevent possible injury.

Cleaning the exterior parts of the appliance

Clean the outside of the unit once a month using a clean and soft, dry or slightly damp cloth (not wet!). Use a dry cloth or a vacuum cleaner soft brush attachment for cleaning the air outlet.

CAUTION! Never use water, wax, polish, or any other chemical cleaning agent to clean the outside of the unit.

Filter maintenance




This air purifier has three filters, which should be cleaned and/or replaced regularly, as appropriate, in order to ensure efficient operation and maintain the unit in good working order. Under normal usage conditions, replace the HEPA filter every 3 months and the carbon filter every 6 months. All filters are available from our after sales support centre (see page 17 for details).

Only the prefilter made of sponge material is washable. Wash it in **warm soapy water, rinse thoroughly** and let it air-dry completely before reinstallation. Replace the filter when required.

CAUTION! Never use water or any household cleaners to clean the HEPA or carbon filters.

Removing/replacing the filters

1. Holding the front panel by the upper part, remove it from the appliance (Fig. 7).
2. Holding the filters by their tags, take them out of the appliance (Fig. 8) and clean/replace the filters as appropriate.
3. After you have replaced the filters into the appliance, reattach the front panel (Fig. 9). Mount the panel onto the bottom of the appliance first (1), then gently push the panel against the body of the appliance (2).



Other Useful Information (Cont.)

Storage

If the appliance is not going to be used for an extended period of time, please store the unplugged appliance safely in the original packaging in a dry location, out of reach of children. Do not place any heavy items on top of appliance during storage as this may result in damage of appliance.


Service, repair and spare parts

If you look after your air purifier it should give you years of good service. Should you experience problems with the appliance that you cannot solve yourself using the advice given in this manual, please contact our after sales support centre for advice. **Do not attempt to open the appliance!**

Our after sales support centre stocks spare E12 HEPA filters, pre-filters and carbon filters for the air purifier. To purchase a filter, call the centre on 1300 886 649 or email us at info@tempo.org.

Technical specifications

Power input	220 – 240V~ 50Hz
Rated power	65W
CADR	200m ³ /h
Room size suitability	25m ²
Dimensions (approx.)	L338 x D195 x H486 mm
Weight (approx.)	4.6kg



CLASS II - DOUBLE INSULATED APPLIANCE

This symbol indicates that the appliance has been designed in such a way that it does not require a safety connection to electrical earth (ground).



E209

The RCM Mark (Regulatory Compliance Mark) indicates that the product complies with the relevant guidelines of the ACMA as well as corresponding government requirements for the safety of electrical devices.

Compliance

This appliance has been fully tested and meets all requirements as set out by standards AS/NZS 60335.1 and AS/NZS 60335.2.65.

Other Useful Information (Cont.)

Responsible disposal

At the end of its working life, do not throw this appliance out with your household rubbish. Electrical and electronic products contain substances that can have a detrimental effect on the environment and human health if disposed of inappropriately. Observe any local regulations regarding the disposal of electrical consumer goods and dispose of it appropriately for recycling. Contact your local authorities for advice on recycling facilities in your area.



 **STIRLING**[®]
Black Edition

Air Purifier

Repair and Refurbished Goods or Parts Notice

Unfortunately, from time to time, faulty products are manufactured which need to be returned to the supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost. **We recommend you save this data elsewhere prior to sending the product for repair.**

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 886 649 or write to us at:

Tempo (Aust) Pty Ltd ABN 70 106 100 252
PO BOX 6056 Frenchs Forest, Sydney, Australia NSW 2086
Telephone: 1300 886 649 (Aust) - Fax: (02) 9975 2688
Tempo Help Desk: 1300 886 649 (Aust)
(Operating Hours: Mon-Sat 09:00am to 06:00pm AEST)
Email: info@tempo.org





Warranty returns

Should you for any reason need to return this product for a warranty claim, make sure to include all accessories with the product.

Product does not work?

If you encounter problems with this product, or if it fails to perform to your expectations, make sure to contact our After Sales Support Centre on 1300 886 649.

For an electronic copy of this manual, go to www.stirlingappliances.com.au and download a copy.

Instruction Manual Revision Index

<u>Version No</u>	<u>Issue Date</u>	<u>Description</u>
V1.0	21 September 2018	Original release
V1.1	27 September 2018	Minor updates, pages 12, 14
V1.2	02 October 2018	Minor updates, pages 10, 11, 12, 14, 17
V1.3	03 October 2018	Minor updates, pages 10, 11, 12, 14, 17
V1.4	09 October 2018	Minor update, page 17