



Quick Start Guide

Model: AFD23L-G

Let's get your new 23L digital air fryer oven ready to use!

This quick start guide contains basic instructions to get you started. For the full picture, please refer to the supplied manual which has comprehensive usage instructions, important safety advice and recipes.

A Setting up the air fryer oven

1 Your new air fryer oven has a gross cavity capacity of 23L – enough space to fit a whole chicken!


2 **Air-frying basket:** When air-frying, use this basket (with the food tray underneath to catch drips) to optimise your cooking results.

NOTE: Maximum food weight for air-frying is 350g. For larger quantities, take the basket out of the oven and shake the food halfway through air-frying.

3 **Food tray:** The food tray can be used alone when baking or roasting, with the air-frying basket when air-frying, or when grilling or toasting to catch drips or crumbs.

4 **Oven wire rack:** The oven wire rack is designed to hold the pizza pan or a baking dish.
NOTE: Maximum food weight for grilling on the wire rack is 400g. For larger quantities, turn over the food halfway through grilling.

5 **Pizza pan:** Use the round pizza pan for baking pizza.



Support guides

The air fryer oven has three support guides at the sides of the cavity for the accessories.

Place the basket in the middle support guide for air-frying and the food tray underneath to catch drips.

Place the pizza pan or a baking dish on top of the wire rack and choose an appropriate support guide when baking or grilling.

Do not place food directly on the bottom of the oven cavity.

Turn over the page for usage instructions ...

B

6

Control panel

C



The **LED screen** displays the set cooking program, time remaining, etc.

The **setting knob** can be turned to the right or left to set the desired cooking function, cooking time, cooking temperature or browning level (darkness), depending on the mode.

You can also press the **AIR FRY** button to select the air-fry function.

To set the cooking time, press **TIME/Darkness** button and then turn the setting knob to the desired cooking time, or browning level when toasting.

To select a function, press the **FUNCTION** button and then turn the setting knob to the desired function: Toast, Air-Fry, Bake, Biscuit, Grill, Pizza, Dehydrate, Warm. The respective function icon will blink on the LED display when it is selected.

To set the cooking temperature, press the **TEMP/Darkness** button and then turn the setting knob to set the desired cooking temperature, or browning level when toasting.

Press the **START/CANCEL** button to start a function once it is selected.

During preheating, press to cancel the preheating and start cooking.

During cooking, press to cancel the operation and return to standby.

Press and hold this button for about 3 seconds to cancel all settings.

7
8
9
10
11
12
13

D

Function settings

Function	Heating element	Default temp. (temp. range) (°C)	Default time (time range) (min)
Toast	Top + bottom	230 (non-adjustable)	Level 4 (Levels 1–6)
Air-Fry	Top + bottom + side + convection	205 (65–205)	25 (1–90)
Bake	Top + bottom	150 (65–210)	50 (1–90)
Biscuit	Top + bottom	160 (65–210)	20 (1–90)
Grill	Top + bottom	210 (non-adjustable)	30 (1–90)
Pizza	Top + bottom	205 (65–210)	15 (1–90)
Dehydrate	Top	65 (non-adjustable)	12h (1min–12h)
Warm	Bottom	80 (55–80)	30 (1–90)



Give us a call

What? You mean this Quick Start Guide didn't have ALL the answers? The manual has more comprehensive instructions, or speak to us. Call our After Sales Support on 1300 886 649.

Well done, you made it! Now sit back and relax ... your new digital air fryer oven is automatically covered by a 3 year warranty.